

Boston *Avidea*[™]
TSU501

REMOTE CONTROL
SETUP AND USE GUIDE



FCC COMPLIANCY

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rule. These limits are designed to provide reasonable protection against harmful interference in residential installations. This equipment generates, uses, and can radiate radio frequency energy and if, not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the equipment does cause harmful interference to radio or televisions reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a different circuit from the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Note If serial or parallel ports are configured, a filtered/shielded serial or parallel cable is recommended to minimize EMI and ensure FCC class B compliance.

TABLE OF CONTENTS

Taking a First Look	2
Using the Avidea Remote	
The Batteries	3
The Remote Control Layout	4
Activating the Avidea Remote	5
The Touch Screen	6
Operating Devices	9
Working with Modes	13
Adjusting the Settings	14
Changing the RF/IR Settings	18
Entering Codes for Other Devices	21
Learning Commands	24
Labeling Buttons and Devices	26
Recording Macros	28
Freedom Edit	32
Maintaining the Avidea Remote	34
Important Notices	34
Cleaning Avidea Remote	34
Troubleshooting	36
General Problems	36
Programming Problems	38
Specifications	39
Table of Brands	40
Index	54

The Avidea Remote Control is a Radio Frequency (RF) and Infrared (IR) remote that can be programmed to operate all the Devices connected to your Avidea System, such as your TV, cable box, satellite receiver, VCR, etc. It has an extensive library of codes for these Devices that can be easily programmed. See "Entering Codes for Other Devices" on p. 21.

In addition, the Avidea Remote can "learn" codes from your existing remote controls that are not already stored in its library. See "Learning Commands" on p. 24.

You can label the touch screen buttons on the Avidea Remote. Characters and numbers are available for labeling as well as various audio and video symbols. See 'Labeling Buttons and Devices' on p. 26.


Recording macros is another feature of the Avidea Remote. If you wish to assign a sequence of commands to a single button, you can record a macro. See 'Recording Macros' on p. 28.

We have provided you with software for use on a PC called Freedom Edit, so that you can create your own screens and create an individualized look for your remote. You can find Freedom Edit on the included CD-ROM and on the Boston Acoustics website www.bostonacoustics.com/avidea. Freedom Edit's online help system will guide you through the process. In the future Freedom Edit will also allow you to upgrade your Avidea Remote. See 'Freedom Edit' on p. 32.


The Batteries

The Avidea Remote requires 3 AA-batteries (3 x 1.5 V) to function. You can use either the supplied batteries or purchase rechargeable batteries.

- 1 Remove the battery cover by releasing the tab and lifting.



- 2 Install the batteries in the battery compartment.
- 3 Replace the battery cover.
After a few seconds, the Avidea Remote starts up automatically and beeps twice to indicate that it is ready for use.




Note: Do not touch the screen or hard buttons during start up as this may cause your remote to lock up. If it does lock up, remove one battery and start again.

The Remote Control Layout

On the Avidea Remote you can perform functions by means of soft and hard buttons.

- Soft buttons are the buttons you can tap on the LCD Touch Screen.
- Hard buttons are the buttons located above, below and on the left side of the LCD touch screen.
 - The 2 hard buttons located above the Touch Screen turn the Avidea System and TV Power on and off.
 - The 4 hard buttons just below the touch screen are Mode, OSD (On Screen Display) Close (Closes OSD), and the Device button. Their labels are displayed at the bottom of the Touch Screen.
 - The hard buttons located at the bottom are for the Avidea System Volume Up/Down, Mute, Channel Up/Down, TV source, and the Navigation buttons.
 - The hard buttons located on the left side of the Avidea Remote are the Backlight button and the Touch Screen Page Up/Down buttons.




Activating the Remote Control

Turning on the Display and the Backlight

The Remote Control's display can be activated in four different ways:

- Tilting the unit more than 50 degrees as illustrated activates the display but not the backlight.
- Pressing the Backlight button on the left side will activate the display and the backlight.
- Tapping the screen gently with your finger or a blunt, soft object like a pencil eraser will activate the display, but not the backlight.
- Pressing any button will activate the display, but not the backlight.



Note: You can set the backlight to automatically activate whenever you use the remote. See 'Adjusting the Backlight Timer' on p. 15.


Whenever batteries are installed in the Avidea Remote or when it is reset, the Remote will beep twice. The Avidea Remote then automatically switches to the Device Page that displays all potential Devices that your Avidea Remote can operate.



Fig 1: Device Page

The Touch Screen

The LCD Touch Screen is divided into different sections:




Using the Soft Buttons

By tapping the soft buttons on the LCD Touch Screen you send commands to the Device you have selected. The name of the active Device is indicated at the top of the touch screen.

Note You can operate the soft buttons in the same way you operate hard buttons on a conventional remote control. When you keep the soft button pressed instead of tapping it, the Avidea Remote keeps sending the command for up to 30 seconds.

Using the Hard Buttons

Hard Buttons can be operated at any time, even without turning on the LCD Touch Screen.




Using the Page Up and Page Down Buttons

The controls to operate your Devices are typically located on different pages. You can scroll through these pages using the Page Up and Page Down buttons on the left side of the touch screen. The page number on the left of the touch screen indicates the active page number and the total number of screens; for example 1/6 means page 1 of 6 pages. The pages also “wrap around” which means you can go to any page in any direction.

Using the Backlight Button

Use the Backlight button to activate the Avidea Remote's display and backlight.

Note If the screen stays black or becomes blank, adjust the contrast using the page buttons on the left side. See Changing the LCD Contrast below. The Remote Control also has an automatic shut-off feature to conserve battery life. See 'Adjusting the Backlight Timer' on p. 15.



Changing the LCD Contrast

To adjust the LCD contrast on the touch screen:

- 1 Press and hold the Backlight button.
The screen lights up.
- 2 While still holding the Backlight button, press the Page Up button once to increase the LCD contrast one level.
The LCD contrast is adjusted one level up.

—or—


Press the Page Down button once to decrease the LCD contrast one level.
The LCD contrast is adjusted one level down.


- 3 Release the Backlight button when the contrast is satisfactory. The LCD contrast can be adjusted to 4 different levels.

Note To adjust the contrast multiple levels, press the Page Up or Page Down button multiple times. When you press and hold the Page Up or Page Down button, the LCD contrast will change only one level.

The Battery Status

The battery icon  indicates the status of your batteries.

When the battery status is low, the Low Battery icon  appears at the top of the touch screen. You can still operate your Devices, but you cannot adjust the settings, enter codes, learn commands or record macros anymore. When you try to perform these actions, a message screen appears.



Replace the batteries to make the Avidia Remote fully functional again. See 'The Batteries' on p. 3 to replace the batteries.

Operating Devices

To operate Devices on your Avidea Remote select the Device Page. This screen displays the available Devices: TV, VCR, Disc, Tuner, Sat, etc.

Activating the Device Page

- Press the Device button.
The Device Page appears.



Fig. 2: The Device button

Selecting a Device on the Device Page

- Tap the soft button of the Device you want to operate.
The first page of the selected Device appears. Using the Page Up and Page Down Buttons you can go to another page of the Device.

You operate Devices using the buttons on your Avidea Remote:

- Soft buttons (touch screen buttons)
- Hard buttons

Selecting Other Device Functions

The second Device Page allows you additional control of your Avidea System. On this page you will find four soft buttons labeled Zone 2, Macros, Listen Modes, and Sleep Timer.



Zone 2

The Avidea System has the ability to provide audio simultaneously and independently in two different listening "zones". With the connection of additional amplification and loudspeakers to the Zone 2 output from your Avidea Control Center you can for instance, enjoy a CD in one room and the FM tuner in another.

To activate a Device from Zone 2 tap the Zone 2 button. Devices available now come up in a new page labeled Zone 2. You operate the Devices as you would in Zone 1. To turn off Zone 2, or return operation to Zone 1, tap the Off or Zone 1 soft buttons at the bottom of the touch screen.





Note If a Zone 2 user selects a Device already in operation in Zone 1 (or vice versa) both users will have control of that same Device. This may cause conflicting use and programming.


Listen Modes

The Avidea Remote allows adjustment of several "listening modes". Listening Modes allow you to use two, five or all six of the system's speakers, depending on program type, format, and personal choice. The Avidea subwoofer is always on, regardless of the number of speakers being used.

Note Page 2 of each Device contains a customized Listening Mode page for that Device.

On the Listening Mode page you will find the following soft buttons:

-  **Display**
Turns the display and lights on the Avidea Control Center on or off. The power button will remain illuminated.
-  **Status**
Brings up the Status Bar on your TV. Shows full system configuration, settings, and Device playback information.
-  **Surround Music**
Uses all six speakers to recreate the ambience of a live musical performance. This is the preset mode for all audio-only Devices.
-  **Stereo**
Uses only two speakers, the front left and front right, allowing Avidea to behave like a traditional 2-channel stereo system.



Surround Movie

Uses all six speakers to recreate a movie theater surround sound experience from sources that are not Dolby® Digital or DTS®. This is the preset mode for all video Devices. When any external Device provides a Dolby Digital or DTS signal, the Avidea System will automatically select the ideal playback mode.

5/6

Turns the rear center speaker on and off. The Avidea System can properly decode the latest surround sound formats: Dolby® Digital Surround EX™ and DTS®-ES™. Both of these formats are available on DVD, and may be provided by some digital cable and satellite programming.

The proper amount of sound will come automatically from the rear center speaker when watching an EX- or ES-encoded movie. A regular Dolby Digital or DTS soundtrack will also send sound to this speaker. However, when watching these movies it is possible that too much sound can come from the rear center speaker, and not enough from the rear left and right speakers. If that is the case, press the 5/6 button to turn the rear center speaker on or off. (The corresponding blue light on the control center will provide a visual confirmation of the status of the rear center speaker.) Simply choose which system configuration you prefer for a specific movie soundtrack.

Subw -/+

Adjusts the output level of the subwoofer to match the type of programming being played. You may also find that a relatively higher subwoofer level is preferred when playing the system at lower volumes. The range of this control is -12 to +12, and a visual indication of any level change will appear on the control center display and your television.

Night (Disc and Changer Device only)

Changes the Avidea System's overall dynamic range while listening to DVD's. This will reduce the difference between a movie's softest and loudest passages, making the movie more suitable for viewing when you are concerned about disturbing others.

Note: The Avidea System has Listening Mode Memory™. It will automatically remember both the Listening Mode and the associated subwoofer level setting for each Device. Let's say that the last time you listened to the Tuner you listened in Stereo and set the subwoofer to +3. You just finished watching a movie in Dolby Digital Surround EX with the rear center speaker on and the subwoofer set to +5. When you switch to Tuner, the system will automatically switch to Stereo, subwoofer +3. Any changes you make to the Listen Mode settings will be stored automatically in the system's memory and recalled the next time you choose that Device.

Macros

A macro allows you to send a sequence of commands using one single button. You can for instance switch on your TV, turn on your cable box and tune to a movie channel, all by pressing a single button. Pressing the **Macros** soft button on the second page of the Device Overview will bring you to a set of Macro soft buttons. Refer to 'Recording Macros' on p. 28 to learn how to program these for your particular needs.


Sleep

You can program your Avidea System to shut off automatically. Using the - and + soft buttons allows you to program the Avidea System to shut off automatically in 15 minute intervals for up to 90 minutes.

Activating The Avidea System 'On Screen Display' (OSD)

Your Avidea System is equipped with an On Screen Display (OSD). The OSD is used to check system status and make adjustments to your Avidea System. Adjustments may include things like TV aspect ratios, speaker levels and parental controls. (See your Avidea Home Theater System Setup and Use Guide for complete information on the use of the OSD)

To access the OSD press the **OSD** hard button at the bottom of the LCD display. You use the **Navigation Buttons** (up/down/left/right/ok) to access specific adjustments within the OSD. Use the **Close** hard button at the bottom of the LCD display to close the OSD.



Note After pushing the Close button it is necessary to press the Device button to return to normal remote operation.

Working with Modes

Operation of the Avidea System or connected Devices requires that the remote be in Use mode. For customizing the Avidea Remote (adjusting the settings, entering codes, learning and labeling buttons, or recording macros) requires switching to the appropriate mode.

The Avidea Remote can be put into 7 different modes. These modes are:

- Use mode** The normal mode for operating your Avidea System and all the connected Devices. See 'Operating Devices' on p. 9.
- Setup mode** For changing the Avidea Remote settings.
See 'Adjusting the Settings' on p. 14.
- Brand mode** For entering the codes for the brands of your Devices using the Avidea Remote's library. See 'Entering Codes for Other Devices' on p. 21.
- Learn mode** For learning commands from other remote controls. See 'Learning Commands' on p. 24.
- Label mode** For re-labeling buttons and re-naming Devices on the Avidea Remote. See 'Labeling Buttons and Devices' on p. 26.
- Macro mode** For recording macros. You can assign multiple commands to one single button. See 'Recording Macros' on p. 28.
- RF/IR mode** For changing mode of communication to connected Devices. You can control other Devices (VCR, satellite receiver) from greater distances. See 'Changing the RF/IR settings' on p. 18.

Note For learning commands, entering codes, and recording macros, it is necessary to select a Device on the Device Page. (See below.)

- 1 On the Device Page tap the soft button of the Device you want to customize.
The first page of the selected Device appears.
- 2 Press and hold the **Mode** button for 3 seconds.
The Mode screen appears.

Note You have to press and hold the Mode button for 3 seconds to prevent accidental changes.



- 3 Select the desired mode from the Mode screen.

Adjusting the Settings

The Avidea Remote settings can be adjusted in the Setup mode.


- 1 Press and hold the **Mode** button for 3 seconds.
The Mode screen appears.
- 2 Tap **Setup** in the Mode screen.
The first Setup page appears.

The Avidea Remote settings consist of 3 setup pages with several settings per page. Use the Page Up and Page Down buttons to navigate to the appropriate setup page.

First Setup Page

On the first setup page you can adjust:

- The LCD timer
- The backlight timer
- The beep volume



Adjusting the LCD Timer

The LCD timer indicates how long the LCD touch screen stays active before it turns off. You can set the timer between 3 and 120 seconds.

Press '+' to increase or '-' to decrease the time the LCD stays active.

- 1 Tap '+' or '-' once to adjust the timer 1 second up or down.
- 2 Press and hold '+' or '-' to adjust the timer in 10 second intervals.

Adjusting the Backlight Timer

The backlight setting indicates how long the backlight of the LCD touch screen and the buttons stays active. The backlight timer can be set between 1 second and 120 seconds. You can also set the backlight in the 'On' setting so that the backlight automatically activates when the touch screen is tapped or a hard button is pressed.

Note The backlight cannot stay active longer than the LCD. If you increase the backlight timer, the LCD timer will automatically increase as well.

Press '+' to increase or '-' to decrease the time the backlight stays active.

- 1 Tap '+' or '-' once to adjust the timer 1 second up or down.
- 2 Press and hold '+' or '-' to adjust the timer in 10 second intervals.
- 3 After you have reached 120 seconds, press the '+' once more to jump to the 'On' state which will automatically activate the backlight whenever the unit is used.

Note Battery life will be reduced when the settings for the LCD timer and the backlight timer are high or when the backlight is activated automatically.

Change the Beep Volume

The beep volume setting adjusts or turns off the volume of all button and system beeps on the Avidea Remote. The beep volume levels are mute, soft, medium and loud.

- Press '+' to increase or '-' to decrease the beep volume.

Second Setup Page

Use the Page Down button to get to page 2.

Adjust the Date

You can set the year, the month and the day.

Press '+' to increase or '-' to decrease the value for the year, month, and day.

- 1 Tap '+' or '-' once to adjust the year, month and day one value up or down.


- 2 Press and hold '+' or '-' to adjust the values for the year and the month more rapidly. The value for the day settings will change per 5 days.

The Avidea Remote will immediately reflect the date change at the top of the screen.

Adjust the Time

- 1 Tap '+' or '-' once to adjust the time 1 minute up or down.
- 2 Press and hold '+' or '-' to adjust the time more rapidly. The time will increase or decrease per 30 minutes.

The Avidea Remote will immediately reflect the time change at the top of the screen.




Third Setup Page

Use the Page Down button to get to page 3.

On the third setup page you can:

- Calibrate the touch screen
- Read information about your Device
- Revert the Avidea Remote



Calibrate the touch screen

- 1 Tap the Calibrate button.
The first instruction "Touch the top left corner" appears.
- 2 Tap as accurately as possible in the center of the image in the upper left corner using a small blunt object such as a pen cap or PDA stylus.
The second instruction "Touch the button right corner" appears.
- 3 Tap as accurately as possible in the center of the image in the lower right corner using a small blunt object such as a pen cap or PDA stylus.
A message screen "Calibration successful" appears for 3 seconds. The setup panel appears again.

Avidea Remote Information

This page contains information that may be important to the dealer in case of a defect. The following information is displayed on this screen:

- Free memory (in percentage), which gives you an indication on how much memory is left to (further) customize the Avidea Remote
- Boot version
- Application version
- Configuration file

Revert

Warning When you revert the Avidea Remote, all customization is lost. You lose all the Avidea Remote settings, Device codes, learned codes, and custom macros. You should save your configuration file to your PC before reverting. See the Freedom Edit on p. 32 for more details.

By tapping the Revert button the Avidea Remote will be reverted to the original configuration file. You might have to revert when you notice that scrolling through pages is slowing down.

- 1 Tap the Revert button.
A message screen appears to confirm or cancel the revert process.



- 2 Press OK or Cancel.


To exit Setup Mode

- 1 Press the Mode button.
The Mode screen appears.
- 2 Tap the Mode button you want to go to.
For normal operation, press Use.

Changing the RF/IR Settings

Your Avidea Remote Control comes from the factory ready to control the Avidea System using Radio Frequencies (RF). RF signals have an operating range of 20 meters (66 feet) in a typical home and unlike traditional Infrared (IR) signals used by most consumer electronics, RF signals can go through


- From the Mode page press the **RF/IR** button.
A message will ask you to select the Device you want to change. Press **Next**.



- On the next screen select the Device you wish to change. The first RF/IR page appears.



- Select the transmission mode. The preset mode for Devices you have connected to your Avidea System is IR. If you want to change this to RF, press the RF button. Tap the Done button to finish.



Now when using the Remote, all commands will be transmitted in RF mode and converted by the Avidea System to IR. The IR signal is then sent through the IR Emitter and delivered to the selected Device.

Note Please do not change the RF settings to IR for Disc or Tuner unless you cannot get your Avidea System to respond to RF commands.

Changing RF Settings- RF ID

If you have more than one Avidea System in your home or perhaps a neighbor in close proximity also has a system, you may find that the RF signals from one system's Remote Control will interfere with the other. In this case you will want to change your system's ID code so that your system operates independently.

- 1 Looking at the rear panel of your Avidea Control Center you will find a dial labeled ID located near the main power line. By rotating the dial, change the setting from the default 'A' setting to another. Note the new setting.
- 2 From the Device Page, press and hold the Mode button for 3 seconds. The Mode screen appears.
- 3 From the Mode page press the RF/IR button. A message will ask you to select the Device you want to change. Press Next.
- 4 On the next screen select the Device you wish to change. The RF/IR page will appear.
- 5 Press the button labeled Change RF Settings. The second RF/IR page will appear.
- 6 On this screen find the box labeled Change RF ID. Scroll to the ID designation that matches the ID knob on the back of the Control Center. Press Done.

Note All Devices must match the ID number selected on the Control Center. If you change one Device you must change all others in the same manner for proper operation.

Changing RF Settings- RF Channel

In rare occasions, other RF controlled Devices (garage door openers, cordless phones) may interfere with the operation of your Avidea Remote Control. If you suspect interference, you can choose another channel to operate your Avidea System.

- 1 Looking at the rear panel of your Avidea Control Center you will find a dial labeled CH located near the main power line. By rotating the dial, change the setting from the default 0 setting to another. Note the new setting.
- 2 From the Device Page, press and hold the Mode button for 3 seconds. The Mode screen appears.
- 3 From the Mode page press the RF/IR button. A message will ask you to select the Device you want to change. Press Next.
- 4 On the next screen select the Device you wish to change. The RF/IR page will appear.
- 5 Press the button labeled Change RF Settings. The second RF/IR page will appear.
- 6 On the next screen find the box labeled Change RF Channel. Scroll to the RF designation that matches the CH knob on the back of the Control Center. Press Done.

Note All Devices must match the CH number selected on the Control Center. If you change one Device you must change all others in the same manner for proper operation.


Entering Codes for Other Devices

The Avidea Remote can operate other Devices (VCR, Satellite Receiver) that are connected to your Avidea System. This eliminates the need to use multiple remotes, as well as allowing a sequence of commands to be programmed as "macros". See 'Recording Macros' on p. 28.

To take advantage of the Avidea Remote's ability to control other brands and Devices, follow these steps.


To enter codes:

- 1 **Locate Code.**
We recommend that you look up the codes for all other Devices that are connected to your Avidea System (located in the back of this manual starting at p. 40). Once the correct codes are located, record them in the space provided below for future reference.
- 2 **Select the Device, e.g. TV, for which you want to enter a code.**
The first page for that Device appears.
- 3 **Press and hold the Mode button for 3 seconds.**
The Mode screen appears.
- 4 **Select Brand.**
The Brand screen appears. 'Brand' and the label of the selected Device appear at the top of the LCD touch screen.



Device	Table	Code
Cable	Cable	
Sat	Sat/DBS	
VCR	VCR	
PVR	PVR	
TV	TV	
Chngr	CD(R)	
Aux	CD(R)	

- 5 **Tap Next to enter the code for your Device.**
The code screen appears. When a code is already stored, as in the illustration below, that code is displayed.



- 6 Enter the code from the 'Table of Brands' from p. 40 onwards.

Note To delete a number, tap  on the LCD touch screen.

In the Table of Brands the brands are ordered alphabetically per Device. Some brands use several codes for the same Device. The codes in the table of brands contain only the basic functions of the Devices. Enter the first code and see how well it operates your Device. If your Device is not responding properly, you should try out the second code for that brand. Try out all codes for the brand until you can operate the Device to your satisfaction.

Note The Brand Codes provided for your remote represent the most comprehensive library currently available. You may discover that certain hard and/or soft buttons do not perform exactly as you expect. If this happens, please use Learning Mode to teach your Avidea Remote the exact desired functionality using your original remote controls. See 'Learning Commands' on p. 24.

- 7 Press **OK** to enter the code for your Device.

When the code is correct, you will hear a confirmation beep. Press the mode button for 3 seconds. The mode screen appears. For normal operation, press Use.


If you enter an incorrect code, you will hear an error beep. A message screen appears.



- 1 Press **OK**.
The Avidea Remote returns to the Brand screen where the incorrect code is displayed.
- 2 Look up the correct code and repeat instructions 6 and 7.


Learning Commands

If a Brand code in the library is not appropriate for your Device, or if buttons on the Avidea Remote do not work as expected, you can program the Avidea Remote by transmitting IR signals from your existing remote controls to the Avidea Remote's learning eye. To do this, place the Avidea Remote and the Device's remote control on a flat, opaque surface, 1 to 4 inches (2 to 10 cm) apart.



The Learn Sequence

- 1 Select the Device, e.g. TV, for which you want to learn a function. The first page for that Device appears.
- 2 Press and hold the Mode button for 3 seconds. The Mode screen appears.
- 3 Tap Learn on the Mode screen. The Avidea Remote is now in Learn Mode. 'Learn' and the label of the selected Device appear at the top of the touch screen.




- 4 Use, if necessary, the Page Up or Page Down button to go to the next button you want to 'teach'.
- 5 Press the soft or hard button you want to 'teach' on the Avidea Remote. The soft button will go from light to dark, and the Learn label changes to Learning, which means the Avidea Remote is ready to receive commands from an existing remote control. The Avidea Remote will wait for 5 seconds to receive an IR code from another remote control.

Note When a hard button is pressed to learn, there is no on-screen feedback to indicate which button is pressed.

- 6 Press and hold the button on the existing remote control you want to 'teach' to the Avidea Remote.

When the Avidea Remote receives an IR code:

- You hear a confirmation beep.
- The label changes from Learning to OK. The Learn sequence has been completed successfully.



For each Device you can 'teach' all soft and hard buttons on the Avidea Remote, except for:

- the Backlight button
- the Page Up and Page Down buttons
- the Mode button
- the Device button

When the Avidea Remote does not receive an IR code in 5 seconds:

- You will hear an error beep.
 - The label changes from Learning to Failed. The Learn sequence has failed.
-
- The Avidea Remote will return to Learn mode. Return to step 5 of the Learn sequence to relearn the button.
- 7 Go to other pages of the selected Device with the Page Up and Page Down buttons. Repeat steps 5 and 6 until you have copied all the commands of the existing remote control.
 - 8 Press Done when you have finished learning commands to the buttons of your choice.
The Avidea Remote returns to Use Mode. You can try out the new IR codes or select another Device to learn.


Labeling Buttons and Devices

You can label or relabel buttons and Devices with:

- Characters in lower case and upper case
- Numbers
- Symbols

To label a Device:

- 1 Go the Device Page.
- 2 Press and hold the **Mode** button for 3 seconds.
The Mode screen appears.




- 3 Tap Label on the Mode screen.
The Avidea Remote is now in Label Mode. 'Label' and the 'Device' appear at the top of the touch screen with the following message on screen.
- 4 Tap Next
- 5 Tap the Device that you want to re-label. The Avidea Remote shows a mini-keyboard. The text you want to re-label is displayed above the keyboard.
- 6 Edit the label.
 - Press Del to delete the current text.
 - Tap the characters, numbers, and/or symbols you want to use.
 - To enter a space, press Space.
 - To display other keyboards with capital letters and symbols, press the Page Up or Page Down button repeatedly.



Note You will hear an error beep, when you selected more characters than can be displayed on the selected button.



- 6 Tap OK to save the changes and return to the Device Page.
-or-
Tap Cancel to Return to the Device Page without saving changes.
- 7 Label all other elements you want. You can navigate to the different pages of the selected Device screens or the Device Overview, using the Page Up and the Page Down button.
- 8 Press Done when you have finished labeling the buttons of your choice. The Avidea Remote returns to Use Mode. You can see the label or select another Device to label.



To label a button within a Device:

- 1 Go the Device Page.
- 2 Select the Device that contains the button you wish

to relabel.

- 3 Press and hold the **Mode** button for 3 seconds.
The Mode screen appears.
- 4 Tap Label, Tap Next, select the button you wish to label, and continue with step number 3 above (p. 27). Use the Page Up/Down keys to access other buttons within the Device.

Recording Macros

A macro allows you to send a sequence of commands using one single button. You can for instance, switch on your TV, turn to a movie channel and prepare your VCR for recording by rewinding the videotape.

To record macros, the Avidea Remote has to be in Macro mode.

- 1 Go the Device Page.
- 2 Select the Device, e.g. TV, with the buttons you want to program as a macro.


Note Basically, you can assign any button as a macro button. However, it is recommended to assign only the reserved macro buttons on the last page of every Device. Use the Page Up and Page Down buttons to go to the last page of the Device.

- 3 Press and hold the **Mode** button for 3 seconds.
The Mode screen appears.
- 4 Tap **Macro** on the Mode screen.
A message screen appears. The Avidea Remote is now in Macro Mode.



5 Tap Next.

The Device screen with the Macro label appears. With the Page Up and Page Down buttons you can go to other screens of the selected Device



6 Tap the soft or hard button you want to select as a macro.

A message screen appears




7 Tap Start.

The Device Overview appears with the 'Recording' label at the top of the screen. From the Device Overview you can go to the different Devices or you can press the Extra hard button to go to the Extra screen with delays and beeps.




- 8 Tap the button of the Device you want to go to.
The Device screen appears.




- 9 Tap the soft or hard buttons with the commands you want to record.
- 10 Press the Page Up and Page Down buttons to go to different screens of the same Device.
—or—
Press the **Device** button to go to the Device Page again.
- 11 To add delays and beeps to the macro, press the **Extra** hard button on the Device Page.
The Extra screen appears.

Note Delays may be required between commands. Some Devices will not respond to another remote command immediately after turning on.



- 1 To add a delay, tap one of the Delay buttons.
By tapping several Delay buttons, the duration of the delay will be increased.
- 2 To add a beep, tap the Beep button.
- 3 Press the Device button to go to the Device Page again.

- 12 Press **Stop** to stop recording.
A message screen appears.



- 13 Press **OK** to save the macro and return to the Mode screen.
The existing command of the selected button is replaced by the macro.

—or—

Press **Cancel** to return to the Mode screen without saving the macro.
The button retains its previous command.

- 14 Set the Avidea Remote in Use mode to test the recorded macro.

If you want to personalize your Avidea Remote even more beyond its standard programming features, Freedom Edit is the tool for you to use. Freedom Edit is the Avidea Remote's companion software that you find on the included CD-ROM.

You can find more information and updates of the software on <http://www.bostonacoustics.com/avidea>.

Freedom Edit is the visual editor for creating and configuring the Avidea Remote Configuration Files (NCF) on your computer. An NCF is a file that is used to define the Avidea Remote behavior and look for the LCD touch screen.


Note It is a good idea to make back-up copies of your own configurations. This can be done with Freedom Edit.

With Freedom Edit you can:

- Define the types and brands of your Devices.
- Generate a new Device Page.
- Design the page layout and the appearance of buttons.
- Configure the behavior of the hard buttons and soft buttons.
- Access Freedom Edit's extended help system by pressing F1.
- Save, duplicate and share NCFs, Devices, buttons, bitmaps or codes with another Avidea Remote.
- Preview the NCF on the Freedom Emulator.
- Download the new configurations to your Avidea Remote and upload the configuration file on your Avidea Remote to Freedom Edit by means of the included serial cable.

1 Plug one end of the serial cable in the serial port on your computer.

2 Plug the other end of the serial cable in the serial port on the Avidea Remote.



Note When the Avidea Remote is connected to the PC, the battery life will be reduced.

Minimum System Requirements

- PC with a Pentium 166 MHz or higher
- Windows 98/ME/XP
- 32 MB of RAM
- 16 MB of free hard disk space
- Free serial port
- CD-ROM player

Installing Freedom Edit from the CD-ROM

1 Place the Freedom Edit CD-ROM in your computer.

Freedom Edit setup will start up automatically. If not, you can install Freedom Edit by double-clicking the FreedomEditSetup.exe file on the CD-ROM.

2 Follow the instructions on screen that will guide you through the installation procedure.

The first time you run Freedom Edit, you have to accept the license agreement. Otherwise Freedom Edit will not run.



Important Notices

Take care not to scratch the touch screen

Use your finger to tap the LCD touch screen or use plastic-tipped pens intended for use with touch screens, such as a PDA stylus.

Never use an actual pen, pencil or other sharp object on the LCD touch screen.

Protect the Avidea Remote from extreme temperatures

Keep the Avidea Remote away from heaters and other heat sources.

The Avidea Remote is not waterproof

The Avidea Remote should not be exposed to rain or moisture.

Do not store or use the Avidea Remote in any location that is extremely damp or wet.

When you have spilled water on the Avidea Remote, you have to take out the batteries and let the Avidea Remote dry for 48 hours before returning the batteries to the Remote.

When you have spilled other liquids like coffee on the Avidea Remote, you can clean it with distilled water. Make sure no water gets into the housing.

The touch screen of the Avidea Remote contains a glass element

Do not drop the Avidea Remote or subject it to any strong impact.

Cleaning the Avidea Remote

Use a soft, damp cloth to clean the Avidea Remote.

If the LCD touch screen of the Avidea Remote is soiled, clean it with a soft cloth moistened with a diluted window-cleaning solution.

Do not use a corrosive detergent or an abrasive sponge.

Avoid the use of abundant water.

Tip You may want to switch your Avidea Remote to Front input to avoid system operation while cleaning. Using the front input eliminates any soft buttons that can be activated during cleaning.

How do I reset the Avidea Remote?


Under normal circumstances, you will never have to reset the Avidea Remote. However, on rare occasions, if the Avidea Remote's touch screen freezes or if you notice unusual behavior, you need to perform a reset to get the Avidea Remote running again. All customized commands and Devices are retained, however you will need to reset the time and date.

1 Remove the battery cover from the back of the Avidea Remote.

You will see the Reset button in the battery compartment.

2 Use an unfolded paperclip or a sharp pencil to carefully press the Reset button.

The Avidea Remote restarts and beeps twice to indicate it is ready for use.



Reset button

How do I revert to the last downloaded configuration?

Reverting to the last downloaded configuration restores the Avidea Remote's Devices and commands to the state last downloaded from your PC. This means that any changes made in the remote are lost permanently. Normally, you never have to revert the Avidea Remote.

1 Press and hold the Mode button for 3 seconds.

The mode screen appears.

2 Tap the Setup button.

3 Press the Page Down button to access setup page 3.

4 Tap the Revert button.

A message screen appears to confirm or cancel the revert process.

5 Press OK or Cancel.

Do I have to calibrate the touch screen?

The Avidea Remote's touch screen is calibrated when it leaves the factory. You only have to calibrate the LCD touch screen:

- When you upgrade the Avidea Remote's software in the future. The Avidea Remote displays a message to calibrate the touch screen. Complete the instructions in 'Calibrate the touch screen' on p. 16.
- When the touch screen buttons do not respond properly. Navigate to Setup Mode first as described in 'Adjusting the Settings' on p. 14 and continue with the instructions in 'Calibrate the touch screen' also on p. 16.



General Problems

The display stays blank or becomes black

- Make sure the batteries are properly installed. See 'The Batteries' on p. 3.
- Press the Backlight button to make sure the Avidea Remote and the backlight are turned on. See 'Turning on the Display and the Backlight' on p. 5.
- Adjust the contrast using the Backlight button and the Page Up or Page Down buttons on the left side of the Avidea Remote. See 'Changing the LCD Contrast' on p. 7.

The display is too light or too dark

- Adjust the contrast using the Backlight button and the Page Up or Page Down buttons on the left side of the Avidea Remote. See 'Changing the LCD Contrast' on p. 7.

The Avidea Remote shuts off automatically

- This is a timeout feature of the Avidea Remote to save power. You can change the time Avidea Remote stays on in the Settings. See 'Adjust the LCD Timer' on p. 14.

IR Devices that have been configured ~~to~~ do not respond to commands from the remote control.

- Check in the IR/6w mode if the Devices you want to operate are set up properly. See 'Changing IR Devices to 6w Control' on p. 18.
- Make sure the IR emitter is placed near the Devices you want to use with 6w signals. See 'Changing IR Devices to 6w Control' on p. 18.
- Be aware that more than one IR emitter may be needed if many IR Devices are stacked or located on different shelves. See 'Changing IR Devices to 6w Control' on p. 18.

A Device responds to ~~some~~ signals and not to others.

It is possible that a Device does not respond properly when operated with RF signals. This is mostly due to IR signals that cannot be properly transmitted as 6w signals. In that case, you have to reconfigure the remote control to operate the Device with IR signals again. See 'Changing IR Devices to 6w Control' on p. 18. You also may be receiving interference from another RF Device. See 'Changing 6w Settings' on p. 20 and p. 21.

Note The brand codes provided with your remote represent the most comprehensive library currently available. You may discover that certain hard and/or soft buttons do not perform exactly as you expect. If this happens, please use Learning Mode to 'teach' your Avidea Remote the exact desired functionality using your original remote controls. See 'Learning Commands' on p. 24.

My Avidea System operates without me controlling it.

You may be receiving interference from another Avidea System. See 'Changing RF Settings' on p. 20 and p. 21.

External Devices do not respond to commands from the Avidea Remote

- Make sure the Avidea Remote is in Use mode. See 'Working with Modes' on p. 13.
- If in IR mode, make sure the Avidea Remote's sending LED is pointed towards the Device you're operating.
- Check if the battery level is low. If so, replace the batteries. See 'The Batteries' on p. 3.
- Check if you have entered the correct codes for your Devices. See 'Entering Codes for Other Devices' on p.21.
- Check if the button you are trying to use is assigned properly via Brand mode, Learn mode or Macro mode. See 'Entering Codes for Other Devices' on p. 21, 'Learning Commands' on p. 24 and 'Recording Macros' on p. 28.
- Calibrate the touch screen. See 'Calibrating the touch screen' on p. 16.

The TV Power button turns my TV On but not Off.

If the code library for your TV includes discrete On/Off commands they will be stored on TV p. 2 as soft buttons. It is possible that only your TV's On command will be stored to the TV Power hard button. To fix this problem simply use Learning Mode and your original TV remote to properly configure your TV Power button. See 'Learning Commands' on p. 24.

The Avidea Remote does not learn commands from an existing remote control

- Press and hold the buttons on the existing remote control for a longer or shorter period of time.
- Make sure the distance between the Avidea Remote and the existing remote control is between 1 and 4 inches (2 to 10 cm). See 'Learning Commands' on p. 24.
- Do not 'teach' commands directly under fluorescent lights.
- Do not 'teach' commands on a reflecting table surface.
- Check if the battery level is low. If so, replace the batteries. See 'The Batteries' on p. 3.
- Check if there is sufficient memory to learn commands. If not, revert the Avidea Remote. See 'Avidea Remote Information' and 'Revert' on p. 17.
- Make sure that the Avidea Remote page label changes from Learn to Learning before pressing the button you are trying to learn on the existing remote.

The Avidea Remote is not recognized by the Freedom Edit software

- Make sure the serial cable is properly connected. See 'Freedom Edit' on p. 32
- Disconnect other equipment connected to the serial ports, e.g. PDA's.
- Plug the serial cable in another serial port.
- Try to connect multiple times.

Programming Problems

Buttons are not sending the correct commands

- Check if you have defined the correct brands for your Devices. See 'Entering Codes for Other Devices' on p. 21.
- Check whether the button of the Device is learned properly. See 'Learning Commands' on p. 24.
- Check whether the macro is recorded properly. See 'Recording Macros' on p. 28.

The Avidea Remote will not switch modes

- Replace the batteries. When the batteries are low the Avidea Remote prevents you from switching modes so that no customization can get lost.

The Avidea Remote is low on memory

- Revert the Avidea Remote. See 'Revert' on p. 17.

The configuration file is corrupted

- When this unlikely event occurs, you have to revert to the original configuration or use Freedom Edit to download a new configuration file. All your customized commands and Devices will be lost and you will have to reprogram your Avidea Remote. If you use Freedom Edit, please make backup copies of your customized configurations. See 'Revert' on p. 17 and 'Freedom Edit' on p. 32.

The Avidea Remote error message

If the error message 'Invalid CF version or corrupt Flash!' occurs:

- Use the Reset button on the back of the Avidea Remote. See 'How do I reset the Avidea Remote?' on p. 35.
- Try to recover the Avidea Remote Configuration File (NCF) by downloading a backup copy or the default file from Freedom Edit. See 'Freedom Edit' on p. 32.
- Go to the Boston Acoustics website <http://www.bostonacoustics.com/avidea> for more information.

The specifications and design of this product are subject to change without notice.

Display	Monochrome touch screen LCD with 4 gray levels and digital contrast control. Resolution: 160 x 100 pixels Blue EL backlighting for LCD and hard buttons
Interface	3-wire (RS232) serial port connector
Software	Built-in Boston Acoustics Radio Frequency codes Library with IR codes to operate different brands Total number of Devices limited only by memory
Infrared (IR)	Infrared sending LED and learning eye Operating distance of 33 feet (10 meters) Learning frequency up to 56 kHz and 455 kHz Learning distance 1 inch (2 cm) up to 4 inch (10 cm)
Radio Frequency	Band: 418 MHz 16 Extender ID's and 4 Channels
Minimum System Requirements	PC with a Pentium 166 MHz or higher Windows 98/ME/XP 32 MB of RAM 16 MB of free hard disk space Free serial port CD-ROM player
Memory	2 MB non-volatile flash memory
Batteries	3 AA-batteries (3 x 1,5V): primary or rechargeable
Power Management	Tilting the unit more than 50 degrees. The display will be activated, but not the backlight. Pressing the backlight button on the left side. The display as well as the backlight will be activated. Tapping the screen gently with your finger or a blunt, soft object like a pencil eraser. The display will be activated, but not the backlight. Pressing any button will activate the display, but not the backlight. Power off automatically
Dimensions	7.2 inch x 2.8 inch x 1.3 inch (183mm x 72mm x 33mm)
Operating Temperature	41°F to 113°F (5°C to 45°C)
Accessories	RS232 cable for PC connection CD-ROM with Freedom Edit software 3 AA-batteries

TABLE OF BRANDS

SETUP CODES FOR CABLE

ABC	0003, 0008, 0014, 0017
Allegro	0153
Americast	0899
Archer	0153
Bell & Howell	0014
Bell South	0899
Century	0153
Citizen	0153
Colour Voice	0025, 0031
Comtronics	0060
Director	0476
FutureVision	0649
Garrard	0153
Gemini	0242
General Instrument	0003, 0276, 0476, 0810
GoldStar	0144
Hamlin	0009, 0273
Jasco	0153
Jerrold	0003, 0012, 0014, 0276, 0476, 0810
Magnavox	0027, 0334
Memorex	0000
Motorola	0276, 0476, 0810, 1106
Pace	0237
Panasonic	0000, 0107
Paragon	0000
Philips	0025, 0027, 0028, 0029, 0030, 0031, 0153, 0242, 0290, 0305, 0317, 0334, 0649, 0652
Pioneer	0144, 0533, 0877, 1877
Pulsar	0000
Quasar	0000
Regal	0273, 0279
Runco	0000
Samsung	0144
Scientific Atlanta	0008, 0017, 0477, 0877, 1877
Sony	1006
Starcom	0003
Supercable	0276
Tocom	0012
Torx	0003
Toshiba	0000
Unika	0153
Universal	0153
Viewstar	0027, 0060
Zenith	0000, 0525, 0899

SETUP CODES FOR SAT/DBS

AlphaStar	0772
Astro Industries	0095
Bell ExpressVu	1167
BSR	0095
Capetronic	0095
Channel Master	0018, 0212
Chaparral	0053, 0209
Crossdigital	1109
Drake	0018, 0064, 0245
DX Antenna	0041
EchoStar	0148, 0159, 0269, 0280, 0775, 1005, 1170, 1171
Expressvu	0775
GE	0566
General Instrument	0627, 0823, 0869, 0891, 0892
GOI	0775
Hitachi	0819
Homecable	0238
HTS	0775
Hughes Network Systems	0749, 1142, 1749
Hytek	0095
Innova	0099
IQ	0210
IQ Prism	0210
Janeil	0152
Jerrold	0627
JVC	0775
Legend	0269
Macom	0018
Magnavox	0722, 0724, 0725, 0726, 0727, 0728, 0729, 0730
Memorex	0269, 0724
Mitsubishi	0749
Motorola	0869
Netsat	0099
Next Level	0869, 0891, 0892
Panasonic	0152, 0247, 0701, 1189
Paysat	0724
Philips	9100, 0099, 0200, 0516, 0722, 0724, 0725, 0726, 0727, 0728, 0729, 0730, 0749, 1076, 1142
Primestar	0627, 0823, 0824, 0825
Proscan	0392
RCA	0143, 0392, 0566, 0855, 1107
Realistic	0052
Samsung	1108, 1109
Shack	0869

SKY	0099
Sony	0639
Star Choice	0869
Star Trak	0180
STS	0041, 0210
Toshiba	0082, 0749, 0790, 1749
Uniden	0052, 0074, 0076, 0238, 0370, 0722, 0724
Zenith	0064, 0856, 1856
SETUP CODES FOR HOME AUTOMATION	
Audio Access	0154
Auto-Tilt	0849
Cableshare	0537
Carlson	0451
Comfortex	0400
Command Center	0252
Cool Breeze	0509
Da-Lite	0780
Draper	0416
Elero	0434
Evergo	0059
GE	0240
Gewa	0095
Lightolier	0184, 1204, 1205, 1206
LiteTouch	0084
Louver Magic	0401
Lutron	0318, 0597, 1239, 1597
Luxaflex	0580
Makita	0409
Nichibeï	0416
One For All	0167, 0252
Panja	1168, 1169, 1170, 1171
Phast	1164, 1165, 1166, 1167
RadioShack	0240
Rainban	0416
Sanyo	0336
Security System	0167
Sharper Image	0846
Silent Gliss	0442
SMC	0458
Solar Drape	0402
Somfy	0438, 0780
Staron	0399
Tash	0613
TouchTronics	0104
UIC	0574
Universal	0252

Universal X10	0167
X10	0167, 0252
Xantech	0573, 0781, 0782, 0783, 0784, 0785, 0786, 0787, 0883, 0884, 0885, 0886
Yokota	0408

SETUP CODES FOR LD

ADS	0305
Aiwa	0203
Carver	0064, 0194, 0323
Denon	0059, 0172, 0241
Disco Vision	0023, 0276
Funai	0203
Harman/Kardon	0194
Hitachi	0023, 0395
Kenwood	0258
Magnavox	0194, 0217, 0241
Marantz	0064, 0194
Mitsubishi	0059
NAD	0059
NEC	0286
Nikkodo	0411
Onkyo	9300
Optimus	0059
Panasonic	0204
Philips	9000, 0064, 0194
Pioneer	0023, 0059
Polk Audio	0194
Quasar	0204
RCA	0073, 0128, 0351
Realistic	0203
Samsung	0323
Sega	0023
Sharp	0001
Sony	0193, 0201, 0270
Technics	0204
Theta Digital	0194
Victor	0245
Yamaha	9200, 9201, 9202, 9203, 0217, 0451

SETUP CODES FOR TAPE

ADC	0171
Aiwa	0015, 0029, 0078, 0079, 0111, 0148, 0197, 0200, 0223, 0263, 0264, 0376, 0435, 0437, 0438
Akai	0188, 0189, 0283, 0306
B & K	0656, 0657, 0658, 0659, 0660, 0661
Bang & Olufsen	0219

TABLE OF BRANDS

BSR	0224
Carver	0029, 0261, 0402
Denon	0076, 0259, 0260, 0371, 0421
Fisher	0074, 0261
Garrard	0300, 0308, 0309, 0375, 0439, 0448
Gradiente	0407
Harman/Kardon	0029, 0182
Hitachi	0163, 0164, 0393, 0394, 0450
Inkel	0085, 0086
JVC	0244, 0273, 0274, 0303, 0304, 0310
Kenwood	0070, 0071, 0092, 0183, 0205, 0233, 0234, 0251, 0386
Koss	0472
Kyocera	0171
Luxman	0012, 0091, 0095, 0266, 0328, 0329
Magnavox	0029, 0083
Marantz	0009, 0029
MGA	0313
Mitsubishi	0283, 0306, 0313, 0314
NAD	0144
Nakamichi	0147, 0151, 0218, 0247, 0248, 0301, 0302
NEC	0165
Nikko	0311, 0312, 0364, 0365
Olympus	0266
Onkyo	9300, 9301, 9302, 9303, 0100, 0135, 0136, 0150, 0282, 0362, 0520
Optimus	0027, 0220, 0300, 0318, 0337, 0338, 0439
Panasonic	0229, 0250, 0272
Philips	9000, 9001, 0029
Pioneer	0027, 0099, 0220
Polk Audio	0029
Proton	0028, 0198
RCA	0026, 0027, 0220, 0261, 0398, 0399
Revox	0190
Samsung	0391, 0392
Sansui	0009, 0029, 0152, 0153, 0257, 0265, 0444, 0445
Sanyo	0261
Scott	0267
Sharp	0205, 0231
Sherwood	0337, 0338, 0409, 0424
Sonic	0375
Sony	0170, 0243, 0291, 0523, 0559
STS	0287
Sylvania	0083
Tandberg	0108, 0109
Teac	0280, 0289, 0308, 0309, 0391, 0392
Technics	0229, 0353

Techwood	0364, 0365
Toshiba	0341, 0342
Victor	0273, 0274
Wards	0027
Yamaha	9200, 9201, 9202, 9203, 9204, 0094, 0097, 0205, 0460, 0478, 0524

SETUP CODES FOR TV

3M	0737
A-Mark	0003
Abex	0032
Admiral	0093, 0463
Advent	0761
Adventura	0046
Aiko	0092
Aiwa	0701
Akai	0030, 0098, 0591
Alaron	0179, 0183, 0216
Ambassador	0177
America Action	0180
Ampro	0751
Anam	0004, 0009, 0068, 0180
Anam National	0055, 0161
AOC	0003, 0019, 0030, 0052, 0137, 0185
Apex Digital	0748, 0767
Archer	0003
Audinac	0391
Audiovox	0003, 0092, 0180, 0451, 0623
Barco	0410, 0479
Baysonic	0180
Belcor	0019
Bell & Howell	0016, 0154
Bradford	0180
Brockwood	0019
Broksonic	0003, 0236, 0426, 0463, 0642
Bush	0355
Candle	0030, 0046, 0056, 0186
Carnivale	0030
Carver	0054, 0170
Casio	0611
CCE	0037, 0217, 0329
Celebrity	0000
Cineral	0092, 0451
Citizen	0030, 0039, 0046, 0056, 0060, 0092, 0186, 0280, 0561
Clairtone	0185
Compaq	0749, 0750
Concerto	0056
Contec	0157, 0158, 0180, 0185

TABLE OF BRANDS

Craig	0161, 0180	Inteq	0017
Crosley	0054	Janeil	0046
Crown	0039, 0180, 0672	JBL	0054
Curtis Mathes	0016, 0030, 0039, 0047, 0051, 0054, 0056, 0060, 0093, 0145, 0154, 0166, 0415, 0451, 0466, 0702, 0747, 1147, 1347	JCB	0000
CXC	0180	Jensen	0050
Daewoo	0019, 0039, 0066, 0067, 0091, 0092, 0451, 0623, 0624	JVC	0036, 0053, 0069, 0160, 0169, 0182
Daytron	0019	Kamp	0216
Denon	0145, 0511	Kawasho	0158, 0216, 0308
Dumont	0017, 0019	Kaypani	0052
Dwin	0720, 0774	KEC	0180
Dynatech	0049	Kenwood	0019, 0030
Ectec	0391	Kloss	0024, 0046, 0078
Eiki	0735	Konka	0628, 0632, 0638, 0703, 0707
Electroband	0000, 0185	KTV	0030, 0039, 0180, 0183, 0185, 0217, 0280
Electrohome	0381, 0389, 0409, 0446	LG	0056, 0442
Emerson	0019, 0038, 0039, 0154, 0158, 0177, 0178, 0179, 0180, 0181, 0182, 0183, 0185, 0236, 0270, 0280, 0282, 0463, 0623, 0624	Loewe	0136, 0633, 0693, 0694
Envision	0030	Logik	0016
Fisher	0154, 0159	Luxman	0056
Focus	0711	LXI	0047, 0054, 0148, 0154, 0156, 0178, 0747
Fujitsu	0179, 0683	Magnavox	0020, 0024, 0028, 0030, 0036, 0054, 0096, 0179, 0186, 0187, 0230, 0386, 1254
Funai	0171, 0179, 0180	Majestic	0015, 0016
Futuretech	0180	Marantz	0030, 0037, 0054, 0444
GE	0021, 0027, 0029, 0047, 0051, 0055, 0093, 0135, 0138, 0174, 0178, 0251, 0279, 0282, 0451, 0747, 1147, 1347	Matsushita	0250, 0650
Gibraltar	0017, 0019, 0030	Megatron	0003, 0145, 0178
GoldStar	0001, 0002, 0019, 0030, 0032, 0056, 0178, 0409	MEI	0185
Goodmans	0360	Memorex	0016, 0056, 0150, 0154, 0178, 0179, 0250, 0463, 1037
Gradiente	0053, 0056, 0170, 0392	Mercury	0001
Grundig	0037, 0195	MGA	0019, 0030, 0150, 0155, 0178
Grunpy	0179, 0180	Midland	0017, 0032, 0039, 0047, 0051, 0135, 0747
Haier	0768	Minutz	0021
Hallmark	0178	Mitsubishi	0014, 0019, 0093, 0098, 0150, 0155, 0178, 0331, 0358, 0592
Harley Davidson	0043, 0179	Motorola	0055, 0093
Harman/Kardon	0054, 0078	MTC	0019, 0030, 0049, 0056, 0060, 0091, 0185, 0216
Harvard	0068, 0180	Multitech	0049, 0180, 0217
Hauppauge	0693	NAD	0156, 0166, 0178
Havermy	0093	NEC	0019, 0030, 0036, 0056, 0170, 0434, 0455, 0497, 0704
Hitachi	0016, 0032, 0038, 0056, 0095, 0097, 0145, 0151, 0173, 0227, 0279, 0409, 0413, 0576, 0577, 0583, 0723, 0770	Netsat	0037
Infinity	0054	Nikko	0030, 0092, 0178, 0317
InFocus	0736, 0738, 0739, 0741, 0752, 0759	Nisato	0391
Innova	0037	Noblex	0430
		Noshi	0018
		NTC	0092
		On Command	0531
		Onkyo	9300

TABLE OF BRANDS

Onwa	0180	0179, 0281, 0747	
Optimus	0154, 0166, 0250, 0650	Semivox	0180
Optiview	0756	Semp	0156
Optonica	0093, 0165	Sharp	0039, 0093, 0153, 0157, 0165, 0220, 0281, 0386, 0398, 0491, 0688, 0689
Orion	0179, 0236, 0463	Shogun	0019
Ovation	0734	Signature	0016
Panasonic	0051, 0055, 0162, 0226, 0250, 0338, 0375, 0650	Simpson	0186, 0187
Penney	0002, 0003, 0018, 0019, 0021, 0027, 0030, 0032, 0039, 0047, 0051, 0056, 0060, 0110, 0135, 0138, 0149, 0156, 0178, 0309, 0747, 1347	Sinudyne	0347
Philco	0019, 0020, 0028, 0030, 0054, 0096, 0145, 0302, 0463	SKY	0037
Philips	9000, 9100, 0037, 0054, 1354, 1454	Sony	0000, 0011, 0080, 0111, 0273, 0353, 0699
Pilot	0019, 0030, 0039	Soundesign	0178, 0179, 0180, 0186
Pioneer	0038, 0166, 0172, 0679	Spectricon	0003, 0137
Portland	0019, 0039, 0092	Squareview	0171
Princeton	0685, 0700, 0717	SSS	0019, 0180
Prism	0051	Starlite	0180
ProPresenter	0728, 0733	Supre-Macy	0046
Proscan	0047, 0747	Supreme	0000
Proton	0003, 0031, 0052, 0178, 0466	Sylvania	0020, 0028, 0030, 0054, 0065, 0096, 0171, 0381
Proxima	0734, 0735, 0737, 0742	Symphonic	0171, 0180
Pulsar	0017, 0019	Tandy	0093
Quasar	0051, 0055, 0165, 0219, 0250, 0650	Tashiko	0588
Radio Shack	0180	Tatung	0003, 0049, 0055, 0396
RadioShack	0019, 0030, 0032, 0039, 0047, 0056, 0154, 0165, 0178, 0409, 0747	Technics	0051, 0250
RCA	0018, 0019, 0029, 0038, 0047, 0051, 0090, 0093, 0135, 0174, 0254, 0278, 0679, 0747, 1047, 1147, 1247, 1347, 1447	Technol Ace	0179
Realistic	0019, 0030, 0032, 0039, 0056, 0154, 0165, 0178, 0180	Technovox	0007
Rhapsody	0183, 0185, 0216	Techwood	0003, 0051, 0056
Runco	0017, 0030, 0251, 0494, 0497, 0603, 0612	Teknika	0016, 0019, 0039, 0054, 0056, 0060, 0092, 0150, 0175, 0179, 0180, 0186, 0312, 0322
Sampo	0030, 0032, 0039, 0052, 0100, 0110	Telefunken	0056, 0074, 0101, 0702
Samsung	0019, 0030, 0032, 0037, 0056, 0060, 0178, 0329, 0408, 0427, 0482, 0702	Telemagic	0735
Samsux	0039	Tera	0031
Sansei	0451	Thomson	0209, 0210
Sansui	0463	TMK	0056, 0177, 0178
Sanyo	0088, 0107, 0146, 0154, 0159, 0232, 0484	TNCi	0017, 0709
Scimitsu	0019	Toshiba	0036, 0060, 0149, 0154, 0156, 1256
Scotch	0178	Tosonic	0185
Scott	0019, 0178, 0179, 0180, 0236, 0309	Totevision	j0039
Sears	0015, 0047, 0054, 0056, 0146, 0148, 0149, 0154, 0156, 0159, 0168, 0171, 0178,	Trical	0157
		Ultra	0391
		Universal	0027
		Vector Research	0030
		Victor	0053
		Video Concepts	0098
		Vidikron	0054, 0242
		Vidtech	0019, 0036, 0178
		Viking	0046, 0312
		Wards	0016, 0019, 0020, 0021, 0027, 0028,

0029, 0030, 0054, 0056, 0080, 0096, 0111,
0165, 0174, 0178, 0179, 0202

Waycon	0156
White Westinghouse	0463, 0623, 0624
Yamaha	0019, 0030
Zenith	0016, 0017, 0092, 0463, 0624
Zonda	0003

SETUP CODES FOR VCR

Action	0317
Admiral	0048, 0209
Advantz	0356
Adventura	0000
Aiko	0278
Aiwa	0000, 0037, 0124, 0307, 0406, 0436, 0468, 0557, 0680
Akai	0041, 0049, 0053, 0061, 0106, 0156, 0175, 0242, 0315
America Action	0278
American High	0035
Asha	0240
Audiovox	0037
Beaumark	0240
Bell & Howell	0104
Blaupunkt	0006
Broksonic	0002, 0121, 0184, 0209, 0211, 0295, 0348, 0361, 0479, 1479
Calix	0037
Canon	0035, 0102, 0167
Capehart	0020, 0554
Carver	0081, 0146
CCE	0072, 0278
Cineral	0278
Citizen	0037, 0278, 1278
Colt	0072
Craig	0037, 0047, 0072, 0240, 0271
Curtis Mathes	0035, 0041, 0060, 0162, 0760, 1035
Cybernex	0051, 0240
Daewoo	0017, 0020, 0045, 0087, 0278, 0554, 0561, 1278
Daytron	0020, 0554
Denon	0042
Dynatech	0000
Electrohome	0037
Electrophonic	0037
Emerex	0032
Emerson	0000, 0002, 0036, 0037, 0043, 0061, 0068, 0088, 0121, 0184, 0208, 0209, 0211,

0212, 0278, 0294, 0295, 0361, 0479, 0510,
0561, 1278, 1479

Fisher	0047, 0054, 0066, 0104
Fuji	0033, 0035
Funai	0000
Garrard	0000
GE	0035, 0048, 0060, 0065, 0202, 0240, 0760, 0761, 0807, 1035, 1060
Go Video	0232, 0279, 0350, 0432, 0526, 0620, 0643, 0663, 0669
GoldStar	0018, 0037, 0038, 0471, 0480, 1237
Gradiente	0000, 0008, 0408
Grundig	0195
Harley Davidson	0000
Harman/Kardon	0038, 0075, 0081, 0146, 0161
Harwood	0068, 0072
Headquarter	0046
HI-Q	0047
Hitachi	0000, 0041, 0042, 0065, 0082, 0089, 0105, 0166, 0235, 0292, 0543, 0544, 0566, 0688
Hughes Network Systems	0042
Jensen	0041
JVC	0008, 0041, 0067, 0206, 0207, 0384, 0486
KEC	0037, 0278
Keen	0693
Kenwood	0038, 0041, 0067, 0384
KLH	0072
Kodak	0035, 0037
Lloyd's	0000, 0208
Logik	0072
LXI	0037
Magnasonic	0278, 0593, 1278
Magnavox	0000, 0035, 0039, 0081, 0103, 0110, 0149, 0519, 0563, 1781
Magnin	0240
Marantz	0035, 0081, 0146, 0161
Marta	0037
Matsushita	0035, 0162, 0454
MEI	0035
Memorex	0000, 0035, 0037, 0039, 0046, 0047, 0048, 0104, 0162, 0209, 0240, 0268, 0299, 0307, 0348, 0454, 0479, 1037, 1162, 1237, 1262
MGA	0043, 0061, 0240
MGN Technology	0240
Minolta	0042, 0105
Mitsubishi	0043, 0048, 0061, 0067, 0075, 0173, 0214, 0242, 0443, 0807
Motorola	0035, 0048

TABLE OF BRANDS

MTC	0000, 0240	Sansui	0000, 0041, 0067, 0082, 0209, 0271, 0479, 1479
Multitech	0000, 0072	Sanyo	0046, 0047, 0104, 0159, 0240, 0268, 0372
NAD	0058	Scott	0043, 0045, 0121, 0184, 0210, 0211, 0212
NEC	0038, 0040, 0041, 0050, 0067, 0082, 0104, 0457	Sears	0000, 0035, 0037, 0042, 0046, 0047, 0054, 0057, 0066, 0104, 0105, 1237
Nikko	0037	Semp	0045
Nikon	0034	Sharp	0048, 0062, 0738, 0807
Noblex	0240	Shintom	0072
Olympus	0035, 0226	Shogun	0051, 0240
Onkyo	0222	Singer	0072
Optimus	0037, 0048, 0058, 0104, 0162, 0432, 0454, 0568, 0593, 0619, 1048, 1062, 1162, 1262	Sonic Blue	0614
Optonica	0062	Sony	0000, 0011, 0022, 0032, 0033, 0034, 0035, 0275, 0586, 0636, 0639, 0640, 1032, 1232
Orion	0002, 0184, 0209, 0295, 0479, 1479	STS	0042
Panasonic	0035, 0077, 0102, 0162, 0225, 0226, 0227, 0246, 0254, 0378, 0454, 0485, 0616, 1035, 1062, 1162, 1262, 1362	Sylvania	0000, 0035, 0043, 0081, 0103, 0110, 1781
Penney	0035, 0037, 0038, 0040, 0042, 0054, 0240, 1035, 1237	Symphonic	0000, 0593
Pentax	0042, 0065, 0105	Tatung	0041
Philco	0035, 0209, 0479	Teac	0000, 0041
Philips	9000, 9001, 0035, 0062, 0081, 0110, 0146, 0403, 0618, 0749, 1081, 1181	Technics	0035, 0162, 0246
Pilot	0037	Teknika	0000, 0035, 0037, 0052
Pioneer	0058, 0067, 0168	Thomas	0000
Polk Audio	0081, 0146	Tivo	0618, 0636
Portland	0020, 0554	TMK	0036, 0208, 0240
Profitronic	0240	Toshiba	0043, 0045, 0057, 0066, 0210, 0212, 0366, 0845
Proscan	0060, 0202, 0760, 0761, 1060	Totevision	0037, 0240
Protec	0072	Unitech	0240
Pulsar	0039, 0051	Vector	0045
Quarter	0046	Vector Research	0038, 0040
Quartz	0046, 0155	Video Concepts	0040, 0045, 0061, 0221
Quasar	0035, 0077, 0162, 0454, 1035, 1162	Videomagic	0037
RadioShack	0000, 1037	Videosonic	0240
Radix	0037	Villain	0000
Randex	0037	Wards	0000, 0035, 0042, 0047, 0048, 0060, 0062, 0072, 0081, 0149, 0161, 0212, 0240, 0760
RCA	0035, 0042, 0048, 0058, 0060, 0065, 0077, 0105, 0106, 0149, 0202, 0240, 0277, 0453, 0619, 0760, 0761, 0807, 1035, 1060	White Westinghouse	0072, 0209, 0278, 1278
Realistic	0000, 0035, 0037, 0046, 0047, 0048, 0062, 0066, 0104	XR-1000	0000, 0035, 0072
ReplayTV	0614, 0616	Yamaha	0038
Ricoh	0034, 0565	Zenith	0000, 0033, 0034, 0039, 0209, 0479, 0637, 1479
Runco	0039		
Salora	0075		
Samsung	0045, 0051, 0053, 0240, 0489		
Samtron	0643		
Sanky	0039, 0048		
		SETUP CODES FOR WEBTV	
		Activy	1139

AOL	1061
AVerMedia	0876
Channel Master	0094
Cool Electronic Stuff Inc.	0318
Elbex	0484
Everquest	0412, 0595
GC Electronics	0231, 0337
HSN Marketing	0595
Instructional Video	0110
Jensen	1165
Kodak	0410
Luxman	0106
Magnavox	1818
Minota	0318
Mitsubishi	1002
Movie Time	0337
MultiVision	0088, 0089, 0205
Nikon	0324
Panasonic	1120
Philips	9100, 1061, 1818
Pinnacle Systems	1268
Pioneer	1010
Princeton	0113, 0295
Pulsar	0085
Rabbit	0081
Recoton	0337
Roctec	0456
Runco	0085
Samsung	1190, 1204
Scan America	0569
Sensory Science	1126
Sharp	1010
Sony	0308, 0850
SuperGuide	0169
Teknika	0367
TeleCaption	0171
Toshiba	0401
TurboScan	0583
Video Link	0403, 0595
Xantech	0403, 0595
Zenith	0085, 0854
SETUP CODES FOR CD(R)	
Acoustic Research	0123
ADC	0018, 0033
Adcom	0155, 0234
Admiral	1072
ADS	0243
Aiwa	0012, 0124, 0157, 0213, 0830

Akai	0156, 0676
Alpine	0341
Anthem	0897
Arcam	0650, 1650
Audio Alchemy	0194
Audio-Technica	0170
B & K	1118, 1119
Bang & Olufsen	0212
BSR	0134, 0194, 0245, 0366
Burmester	0420
California Audio Labs	0029, 0303, 0887
Capetronic	0237
Carrera	0194, 0394
Carver	0157, 0179, 0299, 0365, 0437, 0737
CCE	0643
Clarion	0748, 0753
Classic	1297
Craig	0615
Crown	0122, 0718
DAK	0245
DBX	0254
Denon	0003, 0034, 0766, 0873
DKK	0000
DMX Electronics	0157
Emerson	0155, 0164, 0305, 0469
Eroica	0041
Fisher	0088, 0174, 0179, 0342
Garrard	0245, 0280, 0393, 0420, 0425, 0633, 0788
GE	0009, 0334
Gemini	0625
Genexxa	0032, 0164, 0305
GoldStar	0030, 0383, 0394, 0417, 0525
GPX	1296
Gradiente	0558
Harman/Kardon	0060, 0083, 0108, 0109, 0157, 0173, 0426, 1001, 1008, 1202, 1259
Hitachi	0032, 0126, 0139, 0155, 0227, 0608
Inke	10061, 0065
JVC	0072, 0655, 0656, 0658
Kenwood	0028, 0037, 0190, 0338, 0339, 0340, 0523, 0626, 0677, 0681, 0826, 0858, 0859
Kodak	0287
Koss	0734
Krell	0157
Kyocera	0018
Linn	0157
Luxman	0035, 0093, 0266, 0327, 0328, 0430, 0432, 0483, 0489
LXI	0305

TABLE OF BRANDS

Magnavox	0038, 0129, 0157, 0225, 0305, 0526
Marantz	0005, 0029, 0038, 0157, 0180, 0373, 0435, 0436, 0478, 0514, 0519, 0626
McIntosh	0256, 0287, 0290, 0660
MCS	0029, 0043, 0345, 0454
Memorex	1102, 1103
MGA	0083
Miro	0000
Mission	0157
Mitsubishi	0083, 0098, 0808
MTC	0017, 0420, 0625
Museatex	0283, 0496
NAD	0019, 0299, 0316, 0720, 0721
Nakamichi	0079, 0147, 0439, 0444, 0664
NEC	0043, 0130, 0234
Nikko	0164, 0169, 0170, 0174, 0362, 0525, 0625
NSM	0157, 0332
Onkyo	9300, 9301, 9302, 9303, 9304, 9305, 9306, 9307, 9308, 9309, 9310, 9311, 9312, 9313, 0101, 0102, 0138, 0381, 0868, 1116
Optimus	0000, 0032, 0037, 0087, 0145, 0175, 0179, 0194, 0196, 0280, 0305, 0342, 0420, 0426, 0437, 0468, 0536, 0671, 0775, 0850, 1063, 1075
Panasonic	0029, 0303, 0388, 0752
Parasound	0194, 0420
Philco	0603, 0734
Philips	9000, 9001, 0157, 0274, 0287, 0519, 0626, 0805, 0806
PianoDisc	0706
Pioneer	0032, 0305, 0468, 0551, 1062, 1063
Polk Audio	0157
Proton	0152, 0157
QED	0157
Quasar	0029
RadioShack	1075, 1083
RCA	0009, 0032, 0053, 0155, 0179, 0305, 0468, 0764, 0810, 1062
Realistic	0155, 0164, 0175, 0179, 0180, 0237, 0420
Revox	0113
Rotel	0157, 0420, 0897
SAE	0157
Samsung	0524
Sansui	0157, 0202, 0216, 0305
Sanyo	0087, 0179
Schneider	0560
Scott	0155, 0164, 0305
Sears	0305

Sharp	0037, 0180, 0265, 0861
Sherwood	0061, 0065, 0114, 0180, 0196, 0426, 1067, 1068
Shure	0043
Signature	0108
Sonic Frontiers	0157
Sontec	0067
Sony	0000, 0100, 0185, 0343, 0490, 0604, 0605, 0673, 0727, 0790
Soundesign	0145, 0425, 0865
Staron	0398
STS	0018
Sylvania	0225
Symphonic	0183
Tandberg	0203
Tascam	0420
TDK	1208
Teac	0016, 0045, 0153, 0174, 0180, 0183, 0378, 0393, 0420, 1277
Technics	0029, 0207, 0303
Techwood	0362
Toshiba	0019, 0299
Vector Research	0033, 0109, 0194, 0394, 0417
Victor	0072
Wadia Digital	0761
Wards	0053, 0108, 0157, 0559
Wurlitzer	1183
Yamaha	9200, 9201, 9202, 9203, 9204, 9205, 9206, 9207, 9208, 0036, 0170, 0187, 0261, 0888, 1292
Yorx	0461
Zenith	0615, 0822

SETUP CODES FOR PVR

Action	0317
Admiral	0048, 0209
Advantz	0356
Adventura	0000
Aiko	0278
Aiwa	0000, 0037, 0124, 0307, 0406, 0436, 0468, 0557, 0680
Akai	0041, 0049, 0053, 0061, 0106, 0156, 0175, 0242, 0315
America Action	0278
American High	0035
Asha	0240
Audiovox	0037
Beaumarck	0240
Bell & Howell	0104

TABLE OF BRANDS

Blaupunkt	0006	Keen	0693
Broksonic 0002, 0121, 0184, 0209, 0211, 0295, 0348, 0361, 0479, 1479		Kenwood	0038, 0041, 0067, 0384
Calix	0037	KLH	0072
Canon	0035, 0102, 0167	Kodak	0035, 0037
Capehart	0020, 0554	Lloyd's	0000, 0208
Carver	0081, 0146	Logik	0072
CCE	0072, 0278	LXI	0037
Cineral	0278	Magnasonic	0278, 0593, 1278
Citizen	0037, 0278, 1278	Magnavox	0000, 0035, 0039, 0081, 0103, 0110, 0149, 0519, 0563, 1781
Colt	0072	Magnin	0240
Craig	0037, 0047, 0072, 0240, 0271	Marantz	0035, 0081, 0146, 0161
Curtis Mathes	0035, 0041, 0060, 0162, 0760, 1035	Marta	0037
Cybernex	0051, 0240	Matsushita	0035, 0162, 0454
Daewoo 0017, 0020, 0045, 0087, 0278, 0554, 0561, 1278		MEI	0035
Daytron	0020, 0554	Memorex	0000, 0035, 0037, 0039, 0046, 0047, 0048, 0104, 0162, 0209, 0240, 0268, 0299, 0307, 0348, 0454, 0479, 1037, 1162, 1237, 1262
Denon	0042	MGA	0043, 0061, 0240
Dynatech	0000	MGN Technology	0240
Electrohome	0037	Minolta	0042, 0105
Electroponic	0037	Mitsubishi	0043, 0048, 0061, 0067, 0075, 0173, 0214, 0242, 0443, 0807
Emerex	0032	Motorola	0035, 0048
Emerson 0000, 0002, 0036, 0037, 0043, 0061, 0068, 0088, 0121, 0184, 0208, 0209, 0211, 0212, 0278, 0294, 0295, 0361, 0479, 0510, 0561, 1278, 1479		MTC	0000, 0240
Fisher	0047, 0054, 0066, 0104	Multitech	0000, 0072
Fuji	0033, 0035	NAD	0058
Funai	0000	NEC	0038, 0040, 0041, 0050, 0067, 0082, 0104, 0457
Garrard	0000	Nikko	0037
GE 0035, 0048, 0060, 0065, 0202, 0240, 0760, 0761, 0807, 1035, 1060		Nikon	0034
Go Video 0232, 0279, 0350, 0432, 0526, 0620, 0643, 0663, 0669		Noblex	0240
GoldStar 0018, 0037, 0038, 0471, 0480, 1237		Olympus	0035, 0226
Gradiente	0000, 0008, 0408	Onkyo	0222
Grundig	0195	Optimus	0037, 0048, 0058, 0104, 0162, 0432, 0454, 0568, 0593, 0619, 1048, 1062, 1162, 1262
Harley Davidson	0000	Optonica	0062
Harman/Kardon 0038, 0075, 0081, 0146, 0161		Orion	0002, 0184, 0209, 0295, 0479, 1479
Harwood	0068, 0072	Panasonic	0035, 0077, 0102, 0162, 0225, 0226, 0227, 0246, 0254, 0378, 0454, 0485, 0616, 1035, 1062, 1162, 1262, 1362
Headquarter	0046	Penney	0035, 0037, 0038, 0040, 0042, 0054, 0240, 1035, 1237
HI-Q	0047	Pentax	0042, 0065, 0105
Hitachi 0000, 0041, 0042, 0065, 0082, 0089, 0105, 0166, 0235, 0292, 0543, 0544, 0566, 0688		Philco	0035, 0209, 0479
Hughes Network Systems	0042	Philips	0035, 0062, 0081, 0110, 0146, 0403, 0618, 0749, 1081, 1181
Jensen	0041	Pilot	0037
JVC 0008, 0041, 0067, 0206, 0207, 0384, 0486			
KEC	0037, 0278		

TABLE OF BRANDS

Pioneer	0058, 0067, 0168
Polk Audio	0081, 0146
Portland	0020, 0554
Profitronic	0240
Proscan	0060, 0202, 0760, 0761, 1060
Protec	0072
Pulsar	0039, 0051
Quarter	0046
Quartz	0046, 0155
Quasar	0035, 0077, 0162, 0454, 1035, 1162
RadioShack	0000, 1037
Radix	0037
Randex	0037
RCA	0035, 0042, 0048, 0058, 0060, 0065, 0077, 0105, 0106, 0149, 0202, 0240, 0277, 0453, 0619, 0760, 0761, 0807, 1035, 1060
Realistic	0000, 0035, 0037, 0046, 0047, 0048, 0062, 0066, 0104
ReplayTV	0614, 0616
Ricoh	0034, 0565
Runco	0039
Salora	0075
Samsung	0045, 0051, 0053, 0240, 0489
Samtron	0643
Sanky	0039, 0048
Sansui	0000, 0041, 0067, 0082, 0209, 0271, 0479, 1479
Sanyo	0046, 0047, 0104, 0159, 0240, 0268, 0372
Scott	0043, 0045, 0121, 0184, 0210, 0211, 0212
Sears	0000, 0035, 0037, 0042, 0046, 0047, 0054, 0057, 0066, 0104, 0105, 1237
Semp	0045
Sharp	0048, 0062, 0738, 0807
Shintom	0072
Shogun	0051, 0240
Singer	0072
Sonic Blue	0614
Sony	0000, 0011, 0022, 0032, 0033, 0034, 0035, 0275, 0586, 0636, 0639, 0640, 1032, 1232
STS	0042
Sylvania	0000, 0035, 0043, 0081, 0103, 0110, 1781
Symphonic	0000, 0593
Tatung	0041
Teac	0000, 0041
Technics	0035, 0162, 0246
Teknika	0000, 0035, 0037, 0052
Thomas	0000
Tivo	0618, 0636
TMK	0036, 0208, 0240
Toshiba	0043, 0045, 0057, 0066, 0210, 0212, 0366, 0845
Totevision	0037, 0240
Unitech	0240
Vector	0045
Vector Research	0038, 0040
Video Concepts	0040, 0045, 0061, 0221
Videomagic	0037
Videosonic	0240
Villain	0000
Wards	0000, 0035, 0042, 0047, 0048, 0060, 0062, 0072, 0081, 0149, 0161, 0212, 0240, 0760
White Westinghouse	0072, 0209, 0278, 1278
XR-1000	0000, 0035, 0072
Yamaha	0038
Zenith	0000, 0033, 0034, 0039, 0209, 0479, 0637, 1479
SETUP CODES FOR DVD(R)	
Aiwa	0641
Anaba	0813
Apex Digital	0672, 0717, 0755, 0794, 0795, 0796, 0797
Arcam	0732
Audiologic	0736
B & K	0655, 0662
Blue Parade	0571
Boston Acoustics	9360
Broksonic	0695
Daewoo	0784
Denon	0490, 0634
Emerson	0591
Enterprise	0591
Fisher	0670
GE	0522, 0717, 0815
Genica	0750
Go Video	0715, 0783
GPX	0699, 0769
Gradiente	0651
Greenhill	0717
Harman/Kardon	0582, 0702
Hitachi	0573, 0664
Hiteker	0672
InterAct	0697
JBL	0702

TABLE OF BRANDS

JVC	0558, 0623
Kenwood	0534, 0682, 0737
KLH	0717
Konka	0711, 0719, 0720, 0721
Koss	0651
Lasonic	0798
LG	0801
Loewe	0511
Magnavox	0503, 0675
Malata	0782
Marantz	0539
Microsoft	0522
Mitsubishi	0521
Mobile Authority	0812
NEC	0785
Onkyo	9300, 9301, 9302, 9303, 9304, 0503, 0627, 0792
Optiview	0813
Oritron	0651
Panasonic	0490, 0632, 0677, 0703
Pelican Accessories	0731
Philips	9100, 9101, 0503, 0539, 0646, 0854
Pioneer	0525, 0571, 0632
Princeton	0674
Proscan	0522
Raite	0665
RCA	0522, 0571, 0717, 0822, 1022
Rowa	0823
Saitek	0731
Sampo	0698
Samsung	0573, 0820
Sansui	0695
Sanyo	0670
Sharp	0630
Sherwood	0633
Sony	0533, 0772, 1533
Sylvania	0821
Teac	0809
Technics	0490, 0703
Techwood	0692
Theta Digital	0571
Thrustmaster	0498
Toshiba	0503, 0695, 1045
Tredex	0799, 0800, 0803, 0804
Urban Concepts	0503
Yamaha	9200, 0490, 0545, 0817
Zenith	0503, 0591, 0741

SETUP CODES FOR PREAMP

3M	0854
Accuphase	0382
Acurus	0765
Adcom	1100
Aiwa	0406
Alchemy	0843
Angstrom	0863
Arcam	1213
AudioSource	0011
Biamp	0582
Bose	0674
Boston Acoustics	9360
Carver	0269
Chase Technologies	0802
Chiro	0880, 1182
Curtis Mathes	0300
Denon	0160, 0272, 0522, 1073, 1260
Digital Audio Control	0085
Elan	0647
Forte	0606
Fosgate	0111
GE	0078
GoldStar	0031
Harman/Kardon	0106, 0892, 1018
JBL	0668, 1003
JVC	0331
Kenwood	0297, 0356
Krell	0834
Left Coast	0892
Linn	0269, 0282, 0829
Luxman	0165
Magnavox	0269
Marantz	0269, 0321, 0892
McIntosh	0251
Midiland	1095
Naim	0552
Nakamichi	0321
NEC	0092, 0116, 0131, 0264, 0302
Onkyo	9300, 9301, 9302, 9303, 9304, 9305
Optimus	0300, 0395, 0823
Panasonic	0308, 0521
Parasound	0246, 0661
Philips	9000, 9001, 0269, 0892
Pioneer	0013, 0257, 0300, 0823
Plasse Audio	0733
Polk Audio	0269, 0892
Proceed	1099
QED	0663, 0837

TABLE OF BRANDS

RCA	0300, 0823
Realistic	0395
Rotel	0726, 0793
Sansui	0321, 0623, 0652
Sharp	0226
Shure	0264
Sony	0220, 0465, 0689, 0815, 1126
Soundesign	0078, 0211
Soundstream	0141
Tandberg	0206
Technics	0308, 0372, 0374, 0521
Theta Digital	1049
Toshiba	0353
Victor	0331
Wards	0013, 0078, 0211
Yamaha	9200, 9201, 9202, 9203, 9204, 9205, 9206, 9207, 0133, 0143, 0354, 0504

SETUP CODES FOR Tuner

ADC	0531
Adcom	0002, 0304, 0319, 0616
Admiral	0182
ADS	0375, 1157
Aiwa	0121, 0125, 0158, 0162, 0189, 0249, 0284, 0301, 0361, 0405, 0544, 0601, 0745, 1088, 1089, 1188, 1243, 1321, 1388, 1405
Akai	0076, 0115, 0151, 0224, 0450, 1255
Alco	1390
Anam	1074, 1609
Apex Digital	1257
Arcam	1212, 1214, 1216
Audio Access	0403
Audio Authority	1256
AudioEase	0210
AudioSource	0687
Audiotronic	1189
Audiovox	1390
B & K	0701, 0820, 0840
Bang & Olufsen	0898, 1040
BK	0702
Bondstec	0049
Bose	0238, 0639, 1229
Boston Acoustics	9360
Capetronic	0531, 0690
Carver	0008, 0042, 0189, 0270, 0360, 0412, 1089, 1189
Casio	0195, 0201
Celestion	1264
Clarinette	0195

Compaq	1136
Counterpoint	0253
Creek	0792
Curtis Mathes	0080, 0201
Denon	0004, 0273, 0386, 0771, 1104, 1142, 1160, 1360
EAD	1045, 1046, 1047, 1048
Eclipse	1061
Emerson	0020, 0255, 0424, 0495
Enlightened Audio Designs	1045, 1046, 1047, 1048
Eroica	0051
Fisher	0042, 0219, 0360
Garrard	0146, 0281, 0286, 0407, 0424, 0440, 0463, 0640, 0644, 0744
GE	0260, 0649
Glory Horse	1263
GoldStar	0057
GPX	0744, 1299
Gradiente	0557
Hafler	0146, 0294
Hanwah	0741
Harman/Kardon	0107, 0110, 0189, 0891, 1004, 1005
Hewlett Packard	1181
Hitachi	0228, 0386, 0659, 1273
Inkel	0062, 0066
JBL	0110, 0794, 1002
Jensen	0705, 0713, 0754
JVC	0074, 0464, 0756, 1263
Kansai	0440
Kenwood	0027, 0042, 0077, 0186, 0239, 0313, 0314, 0337, 0569, 1027, 1032, 1051, 1052, 1313, 1569, 1570, 1670
KLH	1138, 1390
Koss	0255, 0424, 0495, 0624, 0636, 0744
Lexicon	1076
Linn	0189
Lloyd's	0195
Luxman	0149, 0166, 0267, 0329, 0330, 0429, 0431
LXI	0181, 0744, 0755
Magnavox	0128, 0189, 0195, 0204, 0222, 0364, 0391, 0531, 1089, 1189
Magnum Dynalab	0729
Marantz	0006, 0039, 0128, 0189, 0200, 0352, 0412, 0455, 1089, 1189, 1289
McIntosh	0258, 0619
MCS	0039, 0044, 0201, 0346
McSilver	0466

TABLE OF BRANDS

Mediacom	0446	Semivox	0255
Memorex	0335	Sharp	0117, 0186, 0262, 1286, 1386
Modulaire	0195	Sherwood	0062, 0066, 0324, 0475, 0491, 0502, 0565, 0653, 1066, 1077
Museatex	0476, 0497	SII	0355
Musicmagic	1089	Sonic	0281
NAD	0320	Sontec	0068
Nakamichi	0075, 0097, 0347, 0876	Sony	0158, 0168, 0415, 0474, 0776, 1042, 1058, 1158, 1258, 1458
NEC	0235	Soundesign	0670
Nikko	0215, 0407, 0466, 0467, 0542, 0543, 0609	Soundstream	0090
Niles	0413, 1173	Stereophonics	1023
NTDE Geniesom	0744	STS	0217
Onkyo	9300, 9301, 9302, 9303, 9304, 0100, 0119, 0135, 0137, 0144, 0380, 0838, 0842	Sunfire	0313, 0314, 1052, 1313
Optimus	0042, 0080, 0177, 0181, 0186, 0219, 0229, 0286, 0440, 0531, 0622, 0670, 0690, 0738, 0744, 0754, 0797, 0801, 0803, 0849, 1023, 1074	Sylvania	0222
Orient Power	0744	Symphonic	0182
Panasonic	0039, 0309, 0367, 0389, 0518, 0763, 1288, 1518, 1763, 1764	Tandberg	0204, 0205
Panor	0350	Teac	0112, 0163, 0298, 0387, 0463, 0870, 1074, 1267
Parasound	0549, 0895, 1124, 1238	Technics	0039, 0208, 0309, 0518, 1308, 1309, 1518
Penney	0044, 0195, 0201, 0449	Techwood	0281, 0344, 0364, 0609
Philco	0479	Thorens	1189
Philips	9000, 0189, 0391, 0412, 0620, 0642, 1089, 1120, 1189, 1268, 1269, 1283	Topline	0767
Pioneer	0014, 0080, 0150, 0244, 0289, 0531, 0630, 1023, 1084, 1123, 1184	Ultrix	0333, 0427
Polk Audio	0189, 1289	Vector Research	0218, 0352
Proscan	1254	Venturer	0849, 1390
Proton	0026, 0047	Victor	0074
Quasar	0039	Wards	0014, 0054, 0080, 0158, 0189
RadioShack	0744, 1263	Welton	0344
RCA	0054, 0080, 0346, 0360, 0530, 0531, 0649, 1023, 1074, 1122, 1123, 1154, 1254, 1390, 1609	Yamaha	9200, 9201, 9202, 9203, 9204, 9205, 9206, 9207, 9208, 9209, 0081, 0082, 0142, 0176, 0186, 0293, 0545, 0712, 1176, 1276
RDS	0242	Yorx	0195
Realistic	0001, 0025, 0163, 0178, 0181, 0182, 0195, 0534	Zenith	0281, 0511, 0622, 0705, 0736, 0744, 0857
Revox	0140, 0250		
Rotel	0007, 0852		
Samsung	0069, 0070, 0112, 1295		
Sansui	0148, 0189, 0193, 0323, 0346, 0593, 1089		
Sanyo	0219, 0448, 0801, 1251		
Schneider	0364		
Scott	0105, 0163, 0322, 0390, 0396, 0418, 0449, 0495		
Sears	0201		

A

- activating
 - a Device, 9
 - Avidea Remote, 4
- adjusting
 - backlight timeout, 15
 - beep volume, 15
 - date, 15
 - LCD contrast, 7
 - LCD timeout, 14
 - settings, 14
 - time, 15

B

- backlight
 - timeout, 15
 - turning on, 4, 7
- Backlight button, 4, 5, 7
- batteries, 3
 - installing, 3
 - status, 8
- battery cover, 3
- beep
 - confirmation beep, 23, 25
 - error beep, 23, 26, 27
 - two beeps, 3
 - volume, 15
- brands
 - defining, 21
 - table, 40
- buttons
 - backlight, 5, 7, 8
 - calibrate, 16
 - delay, 30
 - device, 5, 6
 - hard, 5, 6
 - mode, 5, 6
 - page up and page down, 5, 7
 - reset, 35
 - revert, 16
 - soft, 5, 6
 - touch screen, 6

C

- Calibrate button, 16
- calibrating the touch screen, 16
- CD-ROM, 32
- cleaning Avidea Remote, 34
- connecting to PC, 32

customizing

- adjusting settings, 14
- entering codes, 21
- learning commands, 24
- Freedom Edit, 32
- recording macros, 28
- labeling buttons and devices, 26

D

- date, 16
- Delay button, 30
- Device button, 5, 6
- Device Page, 9
- Devices
 - labeling, 26
 - selecting, 9
- display
 - cleaning, 34
 - timeout, 15
 - turning on, 4, 5

E

- editing, *See* customizing
- entering codes, 21
- eye
 - for learning commands, 5, 24

F

- first time usage
 - activating, 4
 - adjusting settings, 14
 - entering codes, 21

H

- hard buttons, 5, 6

I

- installing
 - Freedom Edit, 32
 - the batteries, 3

K

- keyboard, 27
 - character, 27
 - deleting a character, 27
 - number, 27
 - space, 27
 - symbols, 27

L

Label mode, 13
 Library, 34, 36, 40
 labeling

buttons, 26
 devices, 26

LCD

contrast, 7
 timeout, 14

Learn mode, 13, 24

learning

commands from existing remote
 controls, 24
 distance, 24
 eye, 5, 24

M

Macro mode, 12, 13, 28
 maintaining Avidea Remote, 34
 mode, 13

Brand mode, 13
 Label mode, 13
 Learn mode, 13
 Macro mode, 13
 Setup mode, 13
 Use mode, 13

Mode button, 5, 6

N

NCF, *See* Avidea Remote
 Configuration File
 Freedom Edit, 32
 Freedom emulator, 32

O

overview of devices, 4, 9

P

page number, 6, 7
 Page Up/Page Down buttons, 5, 7
 powering
 battery status, 8
 installing the batteries, 3
 programming, *See* customizing
 Avidea Remote Configuration File,
 32
 Avidea Remote
 cleaning, 34
 information, 17
 reverting, 17, 35

R

recording macros, 28
 relabeling, *See* labeling
 renaming, *See* labeling
 Reset button, 35
 resetting the Avidea Remote, 35
 Revert button, 17
 reverting the Avidea Remote, 17, 35

S

selecting
 devices, 9
 modes, 13
 serial cable, 32
 serial port, 5, 32
 settings
 adjusting, 14
 reverting, 17, 35
 Setup mode, 13
 setup page
 first, 14
 second, 15
 third, 16
 soft buttons, 5, 6
 software, 32
 switching modes, 13
 system requirements, 33, 39

T

table of brands, 40
 time, 16
 timer
 backlight, 7, 15
 LCD, 14
 touch screen, 5, 6
 calibrating, 16
 turning on
 backlight, 4, 5, 7
 display, 4
 Avidea Remote, 4

U

Use mode, 13

W

website, 2, 32, 38



© Boston Acoustics, Inc.

All rights are reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner. Dolby is a registered trademark of Dolby Laboratories. DTS is a registered trademark of Digital Theater Systems, Inc.

Download from Www.Somanuals.com. All Manuals Search And Download.

www.bostonacoustics.com/avidea

- • • Boston Acoustics, Inc. 300 Jubilee Drive Peabody MA 01960 USA
- • • t : 978.538.5000 f : 978.538.5100

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>