

COBY®

COBY MPC951

Setup Guide

Thank you for choosing a COBY MP3 player!



~This guide will cover how to transfer your music CD's into your COBY MP3 player using Windows Media Player 11.

~This guide will also provide common troubleshooting solutions for your COBY MP3 player.

Windows Media Player 11 (WMP11)

The directions in this guide are given for Windows Media Player 11 (WMP11)


If your computer does not have Windows Media Player installed, please download the latest version of Windows Media Player (WMP) from Microsoft's website

www.microsoft.com/windows/windowsmedia/player/download/download.aspx

AUDIO TRANSFER – Getting Started

Transfer your Music CD's into your COBY MP3 player

1) Launch the WMP11 program.



2) Put an audio CD into the CD-ROM drive of your computer.

- ✦ If your computer has an internet connection, WMP will automatically retrieve and display the album information.

Click the “**Rip**” tab and select which “Title” to rip.

 To rip the entire album, check the top check box.




The screenshot shows the Windows Media Player interface. The top navigation bar includes 'Now Playing', 'Library', 'Rip', 'Burn', 'Sync', and 'URGE'. The 'Rip' tab is selected and highlighted in blue. Below the navigation bar, the breadcrumb path is 'Music > Coming Home (D:)'. The main area displays the album 'Coming Home (D:)' with a checkmark icon in the top-left corner of the track list, which is highlighted with a blue border. The track list is as follows:

Album	Track	Title	Length	Rip Status	Artist
Coming Home (D:) Lionel Richie Soul and R&B 2006 ☆☆☆☆☆	1	I Call It Love	3:19	Stopped	Lionel Richie
	2	Sweet Vacation	3:54		Lionel Richie
	3	Why	4:01		Lionel Richie
	4	What You Are	4:12		Lionel Richie
	5	Up All Night	3:36		Lionel Richie
	6	I'm Coming Home	4:18		Lionel Richie
	7	All Around the World	3:34		Lionel Richie
	8	Out of My Head	3:15		Lionel Richie
	9	Reason to Believe	4:46		Lionel Richie
	10	Stand Down	4:02		Lionel Richie
	11	I Love You	4:12		Lionel Richie

3) Set the Rip Options (optional).

Click the “**Rip**” button to set the Rip options. The recommended Rip settings are:


- ✧ Select “Format > mp3”
- ✧ Select “Bit Rate > 128 Kbps”
- ✧ Select “More Options” to change the directory where WMP saves you’re ripped music files. WMP will save your music to your “My Documents > My Music” default folder.



4) Start ripping the CD.

Click the **Rip** button and select "Rip" to start converting the audio CD to MP3/WMA

- ✦ The ripping process will take a few minutes to complete. WMP will save the converted music files in your "My Documents > My Music" default folder.



5) Transfer MP3/WMA Files to Your COBY Player

- ✦ Once you have MP3 or WMA digital music files on your computer, transfer them to your COBY player in order to **listen to music anywhere**.

- * Connect your MP3 player to the computer.
- * The MP3 player will appear under “**MY Computer**” as a “**LOCAL DISK**”.
- * To transfer your Ripped music, go to the ripped folder “My Documents > My Music” and copy or paste or drag and drop your selected files into the LOCAL DISK

NOTE:

To access
Windows
Media Player
Default ripped
folder,


Click on your

button.

Select the

 My Music

folder.



VIDEO TRANSFER – Getting Started

Converting your VIDEO files and transferring it into your player.

Install the Xvid Encoder

1. Insert the driver CD
2. Go into the “Xvid” folder.
3. Double click on the “XviD-1.1.0-30122005” file.
4. This will install the Xvid encoder.

Install the Audio Codec


1. Go back into the root directory of the driver CD.
2. Double click on the “lame 3.96.1” folder.
3. Double click on the “ACM” folder
4. Place your mouse pointer on top of the “LameACM” file and LEFT click on your mouse once. (The file should be



highlighted).

LameACM

5. Once the file is highlighted, RIGHT click on your mouse and




select install.

Install the Conversion Software

1. Go back into the root directory of the driver CD.
2. Copy the “Video Transcoder” folder to your desktop.

Run the conversation Utility

1. Go to your desktop and double click the “Video Transcoder” folder.
2. Double click on the “VirtualDub” folder.
3. Double click on the “ VirtualDub.exe” file .  VirtualDub VirtualDub
4. On VirtualDub, select “FILE” and then “LOAD PROCESSING SETTING.
5. Select the “QCIF-plus” file, to Load the processing setting.
6. **Insert** your video file by selecting “FILE” and “OPEN VIDEO FILE”.
7. **Locate** your Video File by using the pop browser.
8. VirtuaDub will analyze the video file.
9. **Save** the converted file by selecting “FILE” and “SAVE AS AVI”.
10. Name the soon to be converted file and select where the converted file should be saved.

**When the conversion is completed,
Copy and Paste or Drag and Drop the converted files to your
MP3 player “MOVIE” folder.**

Done!!

Common Troubleshooting

Problems

Possible Solutions

No Power

- *The Battery level may be too low. Charge the unit.
- *Ensure that the HOLD button is turned off.
- *Reset the unit.

Music Freezes

- *The file(s) are corrupted or damaged.
- *Make sure your WMA file(s) are not DRM protected.
- *Unsupported file format (ACC, WAV, M4A...Etc.)

No sound after file transfer

- *Make sure your WMA file(s) are not DRM protected.
- *Ensure that the headphone is attached securely to the player.
- *Unsupported file format (ACC, WAV, M4A...Etc.)

My computer does not recognized by the MP3 Player

- *Check the connections.
- *Switch USB ports.
- * Do Not use a USB extension cable

Video Conversion Error

- *Ensure that the original file plays on your computer, If not, then you will need to obtain the codec for that file.
- *Unsupported format

Video Issue

- *Re-encode the video.
- *Play the video file on your computer to confirm that the file is not corrupted.
- *Re-encode the file using the Load Processing setting file "QCIF" or "QCIF-plus".
- *Ensure that the original file plays on your computer, If not, then you will need to obtain the codec for that file.

HDD Error

- *Problem lies with the ribbon cable connected to the hard drive. Ribbon cable is loose.

If you are still having difficulties with your MP3 player, please contact Customer Care, Hours of operation, Monday-Friday 8:00 AM – 8:30:00 PM EST, Saturday and Sunday 9:00 AM – 5:30 PM EST. You can also reach us online at customerservice@cobyusa.com or techsupport@cobyusa.com

1-800-727- 3592

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>